

Valve: SRC/ARC type NO (selfadjustment enabled)

Push:	I	– and wait until red LED flashes
Push:	I	
Push:	II	– hold for 5 sec (clear all stored parameters)
Push:	II	(red+yellow LED)
Push:	I	
	Activate	Valve closes
Push:	II	– to approve valve closed
	Deactivate	Valve opens
Push:	II	– to approve valve is open
Push:	I	(no upper seat-lift)
Push:	I	(no lower seat-lift)
Push:	II	= selfadjustment
Push:	I	
Push:	I	(no maintenance)
Push:	II	Red LED flashes (save & exit by push)

Setup done



Valve: LKB Valve (Butterfly) NO

Push:	I	– and wait until red LED flashes
Push:	I	
Push:	II	– hold for 5 sec (clear all stored parameters)
Push:	II	(red + yellow LED)
Push:	II	(red + yellow + green LED)
Push:	I	
	Activate	LKB valve-closed position (indication-stem down)
Push:	II	– to approve valve closed
	Deactivate	LKB valve-open position (indication-stem up)
Push:	II	– to approve valve is open
Push:	I	(no upper seat-lift)
Push:	I	(no lower seat-lift)
Push:	I	(no selfadjustment)
Push:	I	(no maintenance)
Push:	II	Red LED flashes (save & exit by push)

Setup done





ThinkTop[®] Quick Setup Guide

Easy way to do *ThinkTop*[®] Set-up



Valve: Unique mixproof valve (with lower seat-lift)

Push:	I	– and wait until red LED flashes
Push:	I	
Push:	II	– hold for 5 sec (clear all stored parameters)
Push:	II	(red + yellow LED)
Push:	II	(red + yellow + green LED)
Push:	II	(red + yellow+ green + orange LED)
Push:	I	
Push:	II	– to approve valve is closed
	Activate	Valve opens
Push:	II	– to approve valve is open
Push:	I	(no upper seat-lift)
	Activate	Lower seat-lift active
Push:	II	– to approve
Push:	I	(no selfadjustment)
Push:	I	(no maintenance)
Push:	II	Red LED flashes (save & exit by push)

Setup done



Valve: LKB Valve (Butterfly) NC

Push:	I	– and wait until red LED flashes
Push:	I	
Push:	II	– hold for 5 sec
Push:	II	(red + yellow LED)
Push:	II	(red + yellow + green LED)
Push:	I	
Push:	II	– to approve valve closed (indication-stem up)
	Activate	LKB valve- open position (indication-stem down)
Push:	II	– to approve valve is open
Push:	I	(no upper seat-lift)
Push:	I	(no lower seat-lift)
Push:	I	(no selfadjustment)
Push:	I	(no maintenance)
Push:	II	Red LED flashes (save & exit by push)

Setup done



Valve: Unique 7000, SRC/ARC type NC (selfadjustment disabled)

Push:	I	– and wait until red LED flashes
Push:	I	
Push:	II	– hold for 5 sec (clear all stored parameters)
Push:	II	(red + yellow LED)
Push:	II	(red + yellow + green LED)
Push:	II	(red + yellow+ green + orange LED)
Push:	II	(red + yellow+ green + orange + yellow LED)
Push:	I	
Push:	II	– to approve valve down (closed)
	Activate	Valve opens
Push:	II	– to approve (open)
Push:	I	(no upper seat-lift)
Push:	I	(no lower seat-lift)
Push:	I	(no selfadjustment)
Push:	I	(no maintenance)
Push:	II	Red LED flashes (save & exit by push)

Setup done

